



Tie CCW to STEP / CW for StepDir interface.  
 Tie CCW to DIR / CCW for CW / CCW interface.

Unlocked signal must remain low. Use positive clock edges, only.